

Rear Tugger Application Chart

Note: not all bikes are listed - we just can't measure all bikes out there. So...

If your bike has two rear seat mounting bolts, one on each side of the seat, get the Style 1.

If you have a KTM with the single under-seat bolt, get the Style 1 unless otherwise listed!

If you see your same model, but a different year, chances are good the style listed will work.

If you get one and it doesn't work, send it to us for a full refund.

If you are wondering about a FRONT Tugger, the Style 2 (Original or Extreme Enduro) works for all bikes.

If you are wondering about "Adjust length" column, it's just for us when we do custom embroidery.

The "Extra plastic spacers" are to space out the bushing so the buckle clears the recess in the plastic.

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Beta						
Beta	08	525	Style 1	12.0		
Beta	13-14	250RR	Style 1	16.5		
Beta	13-15	300RR	Style 1	16.5		
Beta	16	Xtrainer	Style 3-4			
Beta	18	300RR	Style 1	17.0		
BMW						
BMW	09	G450X	Style 1	9.0		
BMW	07	G650X	Style 1	13.5		
Cannondale						
Can	03	E440	Style 1	8.5		
Cobra						
Cobra	07	CX50JR	Style 3-4			
GasGas						
GAS	06	EC450	Style 1	10.0		
GAS	?	250	Style 1	10.0		
GAS	07-09	EC300	Style 1	10.0		
GAS	10-12	EC300	Style 1	16.0		
GAS	13	300RR	Style 1	16.0		
GAS		CAMI	Style 1	16.0		
GAS	18	XC300	Style 3-4			
Honda						
Hon	00	XR50	Style 3-4	6.5		
Hon	04-19	CRF50F	Style 3-4	6.5		
Hon		XR70	Style 1	10.5		
Hon	04-07	CR70F	Style 3-4	8.5		
Hon	00	XR80	Style 1	16"		
Hon	04-13	CRF80F	Style 3-4	9.3		
Hon	99	CR80R	Style 1	11.5		
Hon	03-05	CR85R	Style 1	11.3		
Hon	06	CR85R/RE	Style 1	9.0		
Hon	04-13	CRF100F	Style 3-4	9.3		
Hon	13-17	CRF110F	Style 1	10.5		
Hon	18	CRF110F	Style 1	10.5		use M6x30 bolt, 3 plastic washers, stock spacer
Hon	20	CRF110F	Style 1	11.5		
Hon	96	XR100	Style 1	14.0		
Hon	03	XR100	Style 3-4			
Hon	97	CR125R	Style 1	11.0		
Hon	00	CR125R	Style 1	10.5		
Hon	02-03	CR125R	Style 1	11.0		
Hon	04-06	CR125R	Style 1	10.9		
Hon	15-18	CRF125F/FB	Style 3-4			Mount under seat; sandwich between seat and frame

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Hon	04-15	CRF150F	Style 3-4	10.5		
Hon	07-13	CRF150R	Style 1	12.0		
Hon	2001	XR200R	Style 3-4			
Hon	04-15	CRF230F	Style 3-4			
Hon	19	CRF230F	Style 3-4			
Hon	09	CRF230M	Style 1	15.0		street bike version
Hon	09	CRF230L	Style 1	15.0		street bike version
Hon	13-16	CRF250L	Style 1	11.0		seat mount=11"; rear mount=8.5"
Hon	04-12	CRF250X	Style 1	10.3		
Hon	04-06	CRF250R	Style 1	9.8		
Hon	07	CRF250R	Style 1	11.2		
Hon	08-13	CRF250R	Style 1	10.0		
Hon	14-16	CRF250R	Style 1	9.0		Best to use two shoulder spacers on each side
Hon	94	CR250R	Style 1	11.0		
Hon	00-02	CR250R	Style 1	10.5		
Hon	03-04	CR250R	Style 1	11.0		
Hon	05-06	CR250R	Style 1	9.0		
Hon	03-04	XR250	Style 1	12.2	6	
Hon	01-04	XR400R	Style 1	12.2	6	
Hon	19	CRF450L	Style 1	11.0	2	M8x30 bolt, 3 plastic washers, 2 alum spacers each side
Hon	02-04	CRF450R	Style 1	11.0		
Hon	05-06	CRF450R	Style 1	9.8		
Hon	07	CRF450R	Style 1	10.8		
Hon	08-09	CRF450R	Style 1	10.0		
Hon	10-13	CRF450R	Style 1	9.0		
Hon	14-16	CRF450R	Style 1	9.0		Best to use two shoulder spacers on each side
Hon	17-18	CRF450R	Style 1	10.5		4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	19-20	CRF450R	Style 1	10.5	4	M8x30 bolt, stock spacer, 3 or 4 plastic washers
Hon	17	CRF450RX	Style 1	10.5	4	4 plastic & 1 alum spacer on each side, with M8x30 bolt
Hon	05	CRF450X	Style 1	9.8		
Hon	06-16	CRF450X	Style 1	10.8		
Hon	19	CRF450X	Style 1	10.5		Use 2 alum spacers and 3 plastic washers on each side, with M8x30 bolts
Hon	95-00	CR500	Style 1	13.0		
Hon	01, 05	XR650R	Style 1	11.5	6	
Hon	05-15	XR650L	Style 1	18.0		
Husaberg						
Husa	06	FE550E	Style 1	12.0		
Husa	09	FE450	Style 1	12.0		
Husa	2013	FE350	Style 1	12.0		
Husqvarna						
Husq	17	TC50	Style 5			
Husq	18	TC50	--			No obvious solution
Husq	17	TC65	Style 5			
Husq	18	TC65	--			No obvious solution
Husq	15-17	TC85	Style 1	14.0		
Husq	18	TC85	Style 3-4			
Husq	06	CR125	Style 1	10.0		
Husq	17	TC125	Style 5			
Husq	19-20	TC125	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	15	TE125	Style 1	14.0		Use a small aluminum spacer on each side
Husq	09	WR125	Style 1	12.0		
Husq	17	TE150	Style 5			

Make	Year	Model	Style	Adjust Tugger length to... inches	Extra plastic spacers?	Notes
Husq	14	FC250	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16-18	FC250	Style 5			
Husq	20	FC250	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	17-19	FE250	Style 5			
Husq	06	TC250	Style 1	10.0		
Husq	10	TC250	Style 1	12.0		
Husq	16	TC250	Style 1	15.0		
Husq	17	TC250	Style 5			
Husq	19	TC250	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	06	TE250	Style 1	10.0		
Husq	14	TE250	Style 1	12.0		Customer says same as '13 'Berg
Husq	17-18	TE250	Style 5			
Husq	19	TE250i	Style 5			
Husq	12	TCX250	Style 1	10.0		compatible with TC, TXC and WR with this body style - many years; just haven't measured them all
Husq	09	WR250	Style 1	12.0		
Husq	10	WR300	Style 1	12.0		
Husq	12-16	TE300	Style 1	14.0		
Husq	17	TE300	Style 5			
Husq	19	TE300i	Style 5			
Husq	18	TX300	Style 5			
Husq	19	TX300	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	20	TX300i	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	12	TE310	Style 1	12.0		
Husq	15	FC350	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16-18	FC350	Style 5			
Husq	15	FE350S	Style 1	14.0		Use a small aluminum spacer on each side
Husq	17	FE350	Style 5			
Husq	17-18	FE450	Style 5			
Husq	11	TE449	Style 1 special	27.0		special order - extra long Style 1
Husq	14	FC450	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16	FC450	Style 1	19.5		
Husq	17	FC450	Style 5			
Husq	18	FC450	Style 3-4			
Husq	19-20	FC450	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	19	FE450	Style 5			
Husq	18	FX450	Style 5			
Husq	19	FX450	Style 1	16.0		Cut M6 bolts down to ~M6x12 or so
Husq	06	TC450	Style 1	10.0		
Husq	05	TE450	Style 1	10.0		
Husq	15	FE501/501S	Style 1	14.0		Use a small aluminum spacer on each side
Husq	16	FE501	Style 1	14.0		
Husq	17	FE501	Style 5			
Husq	06	TC510	Style 1	10.0		
Husq	08	TE510	Style 1	10.0		
Husq	10	510TC, 510TE	Style 1	12.0		
Husq	08	TE610	Style 1	11.0		
Husq	16	Enduro 701	Style 1	17.0		
Kawasaki						
Kaw	06	KDX50	Style 1			
Kaw	07	KDX50	Style 3-4			
Kaw	04-'09	KX65	Style 1	11.0		
Kaw	16	KX65	Style 1	12.0		

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Kaw	18	KX65	Style 1	12.0	8	Need longer bolt: M6 x 25
Kaw	04-'07	KX85	Style 1	13.5	4	
Kaw	08-09	KX85	Style 1	13.0	4	
Kaw	12	KX85	Style 1	11.0	4	
Kaw	13-16	KX85	Style 1	13.5	6	
Kaw	19	KX85	Style 1	13.0	16	Need longer bolt: M6 x 35
Kaw	04-'17	KX100	Style 1	13.0	4	
Kaw	14-'16	KX100	Style 1	14.5	4	
Kaw	17-18	KX100	Style 1	18.0	10	Need longer bolt: M6 x 30
Kaw	04-13	KLX110, KLX110L	Style 1	11.0	6	Need longer bolt: M6 x 30
Kaw	14-20	KLX110, KLX110L	Style 1	13.0	10	Need longer bolt: M6 x 30
Kaw	04	KX125F	Style 1	11.1		
Kaw	04	KLX125	na	8.5		seat bracket style
Kaw	08-16	KLX140	Style 3-4	18.0		M8 is a tight fit through the grommet but it will work
Kaw	12-13	KLX140, 130L	Style 3-4	--		Must cut holes in plastic and feed Tugger through
Kaw	18-20	KLX140, 140L, 140G	Style 3-4	--		
Kaw	05	KDX200	Style 1	13.0		
Kaw	00-02	KDX220	Style 1	12.5	4	
Kaw	94	KDX250	Style 1	15.0	8	
Kaw	98	KX250	Style 1	9.8		
Kaw	01	KX250	Style 1	9.0		
Kaw	03-07	KX250	Style 1	11.5		
Kaw	04-18	KX250F	Style 1	11.5		
Kaw	04	KLR250	Style 1	17.0		
Kaw	06	KLX250	Style 1			
Kaw	07-09	KLX250S,SF	Style 1	12.0		
Kaw	98	KLX300R	Style 1	12.8		
Kaw	00	KLX300R	Style 1	12.8		
Kaw	04	KLX300R	Style 1	12.8		
Kaw	03	KLX400S	Style 1	11.0		
Kaw	08	KLX450R	Style 1	11.0		
Kaw	06-18	KX450F	Style 1	11.5		
Kaw	19	KX450	Style 1	9.5		
Kaw	00	KX500	Style 1	12.0		
Kaw	01	KX500	Style 1	14.5		
Kaw	04	KLR650	na			
KTM						
KTM	99-17	50 (all)	Style 3-4			
KTM	18-19	50SX	Style 3-4			May want to slot the plastic for the webbing to pass thru
KTM	02-14	65SX	Style 3-4			remove seat to install
KTM	17-18	65SX	Style 1	17.0		
KTM	19	65SX	Style 3-4			
KTM	08-09	65XC	Style 3-4			remove seat to install
KTM	02-12	85SX	Style 3-4			
KTM	13-17	85SX	Style 1	13.0		
KTM	08	85XC	Style 3-4	11.0		open end version
KTM	06-09	105SX	Style 3-4	12.0		remove fender to install
KTM	08	105XC	Style 3-4	11.0		remove fender to install
KTM	02-03	125SX	Style 1			

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
KTM	04-06	125SX	Style 3-4			
KTM	07-13	125SX	Style 1	15.0		
KTM	17	125SX	Style 1	17.5		
KTM	20	125SX	Style 1	22.0		
KTM	07-08	144SX	Style 1	15.0		
KTM	09	150SX	Style 1	15.0		
KTM	12-14	150SX	Style 1	14.0		
KTM	17-18	150SX	Style 1	18.0		
KTM	19	150SX	Style 1	22.0		
KTM	10-11	150XC	Style 1	15.0		
KTM	12-14	150XC	Style 1	14.0		
KTM	18-19	150XC-W	Style 1	18.0		
KTM	01-03	200EXC	Style 1	10.5		
KTM	04-06	200EXC	Style 1	12.8		
KTM	04-05	200SX	Style 3-4			
KTM	06	200 XC-W	Style 1			
KTM	06-07	200 XC	Style 1	13.0		
KTM	08-11	200 XC, XC-W	Style 1	15.0		
KTM	12-15	200 XC, XC-W	Style 1	14.0		
KTM	15	250 Freeride	Style 1	21"		
KTM	17	250 Freeride	Style 1	21"		
KTM	01	250EXC	Style 1	10.5		
KTM	04-06	250EXC	Style 1	12.8		
KTM	08	250EXC	Style 1	15.0		
KTM	18	250EXC-F	Style 1	18.0		
KTM	03-06	250SX	Style 3-4			
KTM	07-11	250SX	Style 1	15.0		
KTM	12-16	250SX	Style 1	14.0		
KTM	19-20	250SX	Style 1	22.0		
KTM	06	250SXF	Style 3-4	13.0		NO tapped holes in subframe stubs; can't use Style 1
KTM	07-11	250SXF	Style 1	15.0		
KTM	12-15	250SXF	Style 1	14.0		
KTM	16-18	250 SX-F	Style 1	18.0		
KTM	19	250 SX-F	Style 1	22.0		
KTM	08-11	250XC	Style 1	15.0		
KTM	12-14	250XC	Style 1	14.0		
KTM	18	250XC	Style 1	18.0		
KTM	19	250XC	Style 1	22.0		
KTM	07-11	250XC-F	Style 1	15.0		
KTM	12-14	250XC-F	Style 1	14.0		
KTM	17-18	250XC-F	Style 1	17.5		
KTM	19	250XC-F	Style 1	22.0		
KTM	07	250XCF-W	Style 1	12.0		
KTM	08-11	250XCF-W	Style 1	15.0		
KTM	12-15	250XCF-W	Style 1	14.0		
KTM	07-11	250XC-W	Style 1	15.0		
KTM	12-16	250XC-W	Style 1	14.0		
KTM	17-19	250XC-W	Style 1	18.0		
KTM	04-06	300MXC	Style 1	13.0		
KTM	04-06	300EXC	Style 1	13.0		
KTM	08	300EXC	Style 1	15.0		
KTM	06-07	300XC	Style 1	12.8		
KTM	08-11	300XC	Style 1	15.0		

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
KTM	12-16	300XC	Style 1	14.0		
KTM	17-18	300XC	Style 1	18.0		
KTM	19	300XC	Style 1	22.0		
KTM	06-07	300XC-W	Style 1	12.8		
KTM	09-11	300XC-W	Style 1	15.0		
KTM	12-16	300XC-W	Style 1	14.0		
KTM	17-19	300XC-W	Style 1	18.0		
KTM	11	350 (all)	Style 1	15.0		
KTM	12-15	350 (all)	Style 1	14.0		
KTM	16	350 XCF-W	Style 1	14.0		
KTM	16	350 EXC-F	Style 1	14.0		
KTM	18	350 EXC-F	Style 1	18.0		
KTM	16-18	350 SX-F	Style 1	18.0		
KTM	19-20	350 SX-F	Style 1	22.0		
KTM	16-18	350 XC-F	Style 1	18.0		
KTM	19	350 XC-F	Style 1	22.0		
KTM	99	380EXC	Style 1	11.0		
KTM	01	400SX	Style 1	10.5		
KTM	01-02	400E/MXC	Style 1	10.5		
KTM	03-06	450SX	Style 3-4			
KTM	07-11	450 SX-F	Style 1	15.0		
KTM	20	450 SX-F	Style 1	22.0		
KTM	03	450EXC	Style 1	10.5		
KTM	18	450EXC-F	Style 1	18.0		
KTM	04-07	450 (all)	Style 1	14.0		
KTM	08-11	450 (all)	Style 1	15.0		
KTM	12-15	450 (all)	Style 1	14.0		
KTM	16	450 XC-W	Style 1	14.0		
KTM	17-18	450 XC-F	Style 1	18.0		
KTM	19	450 XC-F	Style 1	22.0		
KTM	06-07	450SMR	Style 3-4	13.0		
KTM	12-16	500 (all)	Style 1	14.0		
KTM	18	500EXC-F	Style 1	18.0		
KTM	08-09	505XCF	Style 1	15.0		
KTM	02	520EXC	Style 1	10.5		
KTM	01	520EXC	Style 1	10.5		
KTM	04-05	525MXC	Style 1	14.0		
KTM	04-07	525EXC	Style 1	13.5		
KTM	07	525XC	Style 1	13.0		
KTM	06	525SX	Style 3-4	14.0		NO tapped holes in subframe stubs; can't use Style 1
KTM	08-11	530 (all)	Style 1	15.0		
KTM	06	560 SMR	Style 3-4			
KTM	96-04	LC4	Style 1	15.5"		
KTM	04	625 SXC	Style 1	15.5"		
KTM	02	LC4-640E	Style 1	18.5"		
KTM	06-'07	All XC	Style 1	14.0		
KTM	06-'07	All XC-W	Style 1	14.0		
KTM	09-16	690 Enduro	none			none available for this model
KTM	04	950 Adv	Style 1	18"	12	
LEM						
LEM	05	RX3	Style 1	10.0		
Sherco						

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Sherco	2017	300 SE-R	Style 1	18.0		pics available
Sherco	05-08	450 enduro	Style 1			
Sherco	05-08	510 enduro	Style 1			
Sherco	18-19	125 to 500 SC & SE	Style 1	15.0		
Suzuki						
Suz	07	JR50	Style 3-4			
Suz	03, 04	RM65	Style 1	10.8	12	
Suz	19	DRZ50	Style 3-4			
Suz	08-18	DRZ70	Style 3-4			With M8 bolts it's a tight fit but will work
Suz	04	RM80	Style 1	10.4		
Suz	07-18	RM85	Style 1	11.0		
Suz	04	DRZ110	Style 1	10.8		
Suz	04	DRZ125	na	8.8		seat bracket style
Suz	04-06	DRZ125L	na			seat bracket style
Suz	07	DRZ125L	Style 3-4			
Suz	08-18	DRZ125L	Style 1	10.0		
Suz	04	RM125	Style 1	10.3		
Suz	06	RM125	Style 1	10.0		
Suz	15-16	DR200S	Style 1	16.0		
Suz	98	RM250	Style 1	10.3		
Suz	00	RM250	Style 1	10.3		
Suz	04-08	RM250	Style 1	10.5		
Suz	04-18	RMZ250	Style 1	11.0	4	
Suz	07	DRZ250	na	na		
Suz	01	DRZ400S	Style 1	11.0	2	
Suz	04-07	DRZ400S	Style 1	11.0	2	
Suz	00-04	DRZ400E	Style 1	10.5		
Suz	09	DRZ400	Style 1	11.0		
Suz	09-16	DRZ400SM	Style 1	11.0		Could also mount to brackets farther back than the seat - 15" in that case
Suz	09	DRZ400Dual	Style 1	11.0		
Suz	17-18	RMX450Z	Style 1	11.0	2	
Suz	06-11	RMZ450	Style 1	11.0		
Suz	12-17	RMZ450	Style 1	12.5		
Suz	18	RMZ450	Style 1	10.5		
Suz		DR650	Style 1	15.0		
TM						
TM	00	300 EN	Style 1	10.0		
TM	07-09	250 enduro	Style 1	14.5		
TM	15	85MX	Style 1	11.0		
Yamaha						
Yam	08-17	PW50	Style 3-4			
Yam	05-17	TTR50	Style 3-4			
Yam	81	PW80	Style 1			
Yam	04-06	PW80	Style 3-4			
Yam	04-15	YZ85	Style 1	10.5		
Yam	04	TTR90	Style 3-4			
Yam	08	TTR110	Style 1	12.0		
Yam	09	TTR110	Style 3-4			
Yam	12	TTR110	Style 1	12.0		
Yam	16-18	TTR110	Style 3-4			

Make	Year	Model	Style	Adjust Tugger length to..., inches	Extra plastic spacers?	Notes
Yam	01-07	TTR125, TTR125L	Style 1	10.5	6	
Yam	08-12	TTR125, TTR125L	Style 1	11.0	6	
Yam	13-18	TTR125, TTR125L	Style 1	11.0	6	Right side mounts under plastic; left side needs 8 plastic spacers and M8x35 bolt
Yam	19	TTR125, TTR125L	Style 3-4			
Yam	00-01	YZ125	Style 1	8.8	4	
Yam	02-07	YZ125	Style 1	10.5	4	
Yam	09	TW200	Style 3-4			Need to double check if M6 or M8 bolts
Yam	04	XT225	Style 1	14.3		
Yam	04	TTR225	Style 1	15.5		frame has M8 threaded holes to use
Yam	06-17	TTR230	Style 1	9.5		
Yam	05	TTR250	3-4 special			Special, longer style 3-4: 28" 'tween grommets
Yam	02-06	WR250F	Style 1	9.5		
Yam	07-12	WR250F	Style 1	10.5		
Yam	15-16	WR250F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	08-09	WR250R	Style 3-4			street legal; uses two seat mounting bolts underneath
Yam	12	WR250R	N/A			Customer reports neither Style 1 nor Style 3-4 work
Yam	14-16	WR250R	Style 3-4			Customer very happy - see pics
Yam	08-09	WR250X	Style 3-4			need to trim the plastic a bit
Yam	96	YZ250	Style 1	10.0	6	
Yam	99	YZ250	Style 1	9.0	6	
Yam	01	YZ250	Style 1	8.5	4	
Yam	02-06	YZ250	Style 1	10.0	4	
Yam	17	YZ250	Style 1	10.5		
Yam	01-12	YZ250F	Style 1	10.0		
Yam	13-18	YZ250F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	19	YZ250F	Style 1	9.5		
Yam	15	YZ250FX	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	15	YZ250X	Style 1	10.0		
Yam	09	XT250	Style 1	11.0		replaces existing handles - have to trim the plastic a bit
Yam	98	YZ400F	Style 1	8.6		
Yam	01	WR426F	Style 1	8.8		
Yam	02	YZ426F	Style 1	8.6		
Yam	04-06	YZ450F	Style 1	9.1		
Yam	08-12	YZ450F	Style 1	10.0		
Yam	13-17	YZ450F	Style 1	10.0	6	Need to use longer M8 bolts - M8 x 30
Yam	18	YZ450F	Style 1	9.0		
Yam	19-20	YZ450F	Style 1	9.5		
Yam	18	YZ450FX	Style 1	10.5	6	Need to use longer M8 bolts - M8 x 30
Yam	19	YZ450FX	Style 1	9.5		
Yam	04-07	WR450F	Style 1	9.1		
Yam	08-17	WR450F	Style 1	10.5		
Yam	84	IT490	Style 1	20.5		
Yam	92	WR500	Style 1	17.2	6	